



# CUBE CLOCK



## 1. Battery instalment.


Open the battery compartment on the bottom of the Cube Clock and insert one AA battery.

Warning: Do not use old or rechargeable batteries.



## 2. How it works.

Rotate the top to display the clock, alarm, calendar or temperature mode.



## 3. Clock.





(a). Rotate the top until the clock mode is displayed.

Press the UP or DOWN button to choose between a 12 hour (am/pm) or 24 hour format.

(b). To set the correct time, press the SET button.

When the hour starts flashing, press the UP or DOWN button to select the correct hour, then press the SET button to save it.

When the minutes starts flashing, press the UP or DOWN button to select the correct minutes, then press the SET button to save it.



## 4. Calendar.



(a). Rotate the top until the calendar mode is displayed.

Year, date and day of the week are displayed in sequence.

(b). To set the correct year, press the UP or DOWN button until the year is displayed.





Press the SET button, then use the UP or DOWN button to select the correct year and press the SET button to save.

(c). To set the correct date, press the UP or DOWN button until the date is displayed.

Press the SET button, then use the UP or DOWN button to select the correct date and press the SET button to save.

(d) To set the correct day of the week, press the UP or DOWN button until the day of the week is displayed.

Press the SET button, then use the UP or DOWN button to select the correct day of the week, then press the SET button to save.



## 5. Alarm.




(a). Rotate the top until the alarm mode is displayed.

Press the UP or DOWN button to turn the alarm on or off.


When the alarm is on, the word ON is displayed as well as a small alarm icon.

When the alarm is off, the word OFF is displayed and no alarm icon is showing.

(b). To set the alarm, press the SET button, then follow the same procedure as in setting the clock (see 3 above).



Turn On



Turn Off






## 6. Temperature.



Rotate the top until the temperature mode is displayed.

The current temperature will automatically and sequentially be displayed in degrees Celsius and Fahrenheit.

To quickly shift between both scales, press the UP or DOWN button.



CE FC  Made in China

HK Design Registered: 0702663.4

China Design Registered: 200730174533.2

Europe Design Registered: EU 000827043

US Copyright Pending